


Chapter 3-1


Transmitters

A radio transmitter transforms electric power into a radio frequency alternating current which is sent to the antenna and the antenna radiates the energy as radio waves.

The simplest transmitter would be an oscillator set at the carrier frequency and the oscillator turned the oscillator on and off. Very impractical and weak transmitter but covers the basics.



A simple audio transmitter is shown below.



The information to be transmitted is modulated with an oscillator at the carrier frequency. This modulated signal is amplified and sent the antenna.

Oscillator

An oscillator circuit generates the radio frequency signal which is usually a sine wave of constant amplitude. This is called the *carrier wave* because it produces the radio waves which "carry" the

Australian Amateur Radio Foundation Licence Theory

information. In modern transmitters, the oscillator is precisely controlled by the vibrations of a quartz crystal. The frequency of the carrier wave is considered the frequency of the transmitter.

Varying the frequency of the oscillator allows the transmitter to cover a broad band of frequencies.

Transmissions





There are two basic types of transmission.

- **Telegraphy** - This is the transmission of information by Morse code. (Dots and Dashes)
- **Telephony** – This is the transmission of information by voice.

Modulation

Modulation is the process of superimposing an information audio signal onto the carrier signal. If we want a HF transmitter at 28 MHz there are several ways to superimpose the and the audio range of 300 hertz to 3.4 Kilohertz onto the carrier signal.

In the amateur radio arena, there are four primary methods of modulating an analogue signal with an intelligent signal. The primary modulation methods used by radio amateurs are AM , FM, CW and SSB.

Amplitude modulation (AM)	AM is a modulation technique where the amplitude of the carrier is varied in proportion to that of the message signal.	
Frequency modulation (FM)	FM is a modulation technique where the frequency of the carrier wave is varied by the message signal.	
Continuous Wave (CW)	The term continuous wave refers to a method of radio transmission in which a sinusoidal carrier wave is switched on and off as in Morse code.	
Single-Sideband modulation (SSB)	SSB is a refinement of amplitude modulation, SSB uses transmitter Single-sideband modulation avoids this bandwidth increase, and the power wasted on a carrier, at the cost of increased device complexity and more difficult tuning at the receiver.	 <p style="text-align: center; font-size: small;">Wikipedia Single-sideband modulation - Wikipedia</p>

Australian Amateur Radio Foundation Licence Theory

Deviation and Power

The Foundation licence operator can only transmit a power level of no more than 10 W peak.

Voice peaks when using SSB should not exceed 10 W. This is referred to as peak envelope power (PEP) and often referred by the letters P_x . P_y is the average or mean power.

When transmitting FM, the carrier power does not change with the voice like SSB. Instead, the carrier signal is said to deviate with the modulation. Again, the carrier power cannot exceed 10 W.

Excessive modulation of any carrier can cause the carrier signal to be distorted. This distortion can cause interference to other operators.

Awareness of the microphone gain control will help keep the signal power within limits.

Occupied bandwidth is the frequency spectrum (space) on that frequency you occupy when you transmit.

Go to Chapter 3-1 Questions.

Have fun and stay safe